

LD
5655
A761
C48
NO. 421
VPI
Spec.

Cleaning Closet

Keep the right cleaning supplies and equipment in a closet. Look for a convenient place to build a cleaning closet. There is space for it in almost every home—under the stairs, in the back hall, in a corner of the kitchen, or at the head of the basement stairs.

The closet shown in the drawing is 4' wide, 6' high, and 2' deep. The left door has 7" shelves on it. The shelves in the closet are 12" deep.

The right-hand door is used for hanging light cleaning equipment; and the space behind it for a sweeper, wax polisher, etc.

If $\frac{3}{4}$ " plywood can be obtained, it is best suited for the closet. If not available, use any good, well-dried lumber.

Note that the plan drawing shows the doors closed, with dotted lines to indicate an open position.

